

BALLANTINE

Bobcat® LT102

Trencher Replacement Parts



American Made.
American Strong.™

www.ballantineinc.com

Faster Service
Better Quality
Lower Prices

Replacement Parts for Bobcat® Trencher Attachments

Bobcat® is a registered trade mark of Bobcat Company.

All manufacturers' names, numbers, symbols and descriptions are used for reference purposes only and it is not implied that any parts listed are the products of the manufacturers.

Main Office

840 McKinley Street
Anoka, Minnesota 55303

Branch Office

675 Wesleyan Drive South West
Atlanta, Georgia 30336

Branch Office

9647 Santa Fe Springs Rd.
Santa Fe Springs, California 90670


Call Toll Free To Inside Sales

1/800/328/2424

FAX 1-763-427-2277


Email: parts@ballantineinc.com

www.ballantineinc.com




Bare Chain 1.654" Pitch Every 4th

Ballantine Part No.	Dig Depth	Description
ZB1640400B13	24"	Bare Chain 13 Station
ZB1640400B17	36"	Bare Chain 17 Station



Bare Chain 1.654" Pitch Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB1640200B26	24"	Bare Chain 26 Station
ZB1640200B34	36"	Bare Chain 34 Station



Bare Chain 1.654" Pitch Heavy Duty Anti Back Flex

Ballantine Part No.	Dig Depth	Description
TA1654HD00B26	24"	Bare Chain 26 Station
TA1654HD00B34	36"	Bare Chain 34 Station

Bobcat® LT102 Attachment



Cup Cutter Assemblies 1.654" Pitch Every 4th

Ballantine Part No.	Dig Depth	Description
M564044C13	24"	Cup Cutter Assembly 4" Cut 13 Station
M564044C17	36"	Cup Cutter Assembly 4" Cut 17 Station
M564064C13	24"	Cup Cutter Assembly 6" Cut 13 Station
M564064C17	36"	Cup Cutter Assembly 6" Cut 17 Station
Wider Cutting Widths Available Upon Request		



Cup Cutter Assemblies 1.654" Pitch Every 2nd


Ballantine Part No.	Dig Depth	Description
M564042C26	24"	Cup Cutter Assembly 4" Cut 26 Station
M564042C34	36"	Cup Cutter Assembly 4" Cut 34 Station
M564062C26	24"	Cup Cutter Assembly 6" Cut 26 Station
M564062C34	36"	Cup Cutter Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Anti Back Flex Cup Cutter Assemblies, 1.654" Every Second

Ballantine Part No.	Dig Depth	Description
M1654HD042C26	24"	Cup Cutter Assembly 4" Cut 26 Station
M1654HD042C34	36"	Cup Cutter Assembly 4" Cut 34 Station
M1654HD062C26	24"	Cup Cutter Assembly 6" Cut 26 Station
M1654HD062C34	36"	Cup Cutter Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		

Bobcat® LT102 Attachment



Terminator & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042TM26	24"	1/2 Terminator & 1/2 Cup 4" Cut 26 Station
ZB164042TM34	36"	1/2 Terminator & 1/2 Cup 4" Cut 34 Station
ZB164062TM26	24"	1/2 Terminator & 1/2 Cup 6" Cut 26 Station
ZB164062TM34	36"	1/2 Terminator & 1/2 Cup 6" Cut 34 Station


Wider Cutting Widths Available Upon Request



Heavy Duty Anti Back Flex Terminator & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
T1654HD042M26	24"	1/2 Terminator & 1/2 Cup 4" Cut 26 Station
T1654HD042M34	36"	1/2 Terminator & 1/2 Cup 4" Cut 34 Station
T1654HD062M26	24"	1/2 Terminator & 1/2 Cup 6" Cut 26 Station
T1654HD062M34	36"	1/2 Terminator & 1/2 Cup 6" Cut 34 Station


Wider Cutting Widths Available Upon Request



Bolt On Terminator Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042T26	24"	Terminator Bolt On 4" Cut 26 Station
ZB164042T34	36"	Terminator Bolt On 4" Cut 34 Station
ZB164062T26	24"	Terminator Bolt On 6" Cut 26 Station
ZB164062T34	36"	Terminator Bolt On 6" Cut 34 Station

Wider Cutting Widths Available Upon Request




Heavy Duty Anti Back Flex Bolt On Terminator Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
T1654HD042T26	24"	Terminator Bolt On 4" Cut 26 Station
T1654HD042T34	36"	Terminator Bolt On 4" Cut 34 Station
T1654HD062T26	24"	Terminator Bolt On 6" Cut 26 Station
T1654HD062T34	36"	Terminator Bolt On 6" Cut 34 Station


Wider Cutting Widths Available Upon Request

Bobcat® LT102 Attachment




Rock & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
ZB164042RM26	24"	1/2 Carbide & 1/2 Cup 4" Cut 26 Station
ZB164042RM34	36"	1/2 Carbide & 1/2 Cup 4" Cut 34 Station
ZB164062RM26	24"	1/2 Carbide & 1/2 Cup 6" Cut 26 Station
ZB164062RM34	36"	1/2 Carbide & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		




Heavy Duty Anti Back Flex Rock & Cup Combination Assemblies, 1.654" Every 2nd

Ballantine Part No.	Dig Depth	Description
TA1654HD042M26	24"	1/2 Carbide & 1/2 Cup 4" Cut 26 Station
TA1654HD042M34	36"	1/2 Carbide & 1/2 Cup 4" Cut 34 Station
TA1654HD062M26	24"	1/2 Carbide & 1/2 Cup 6" Cut 26 Station
TA1654HD062M34	36"	1/2 Carbide & 1/2 Cup 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Rock & Frost Assemblies, 1.654" Every 2nd


Ballantine Part No.	Dig Depth	Description
ZB164042R26	24"	Rock & Frost Assembly 4" Cut 26 Station
ZB164042R34	36"	Rock & Frost Assembly 4" Cut 34 Station
ZB164062R26	24"	Rock & Frost Assembly 6" Cut 26 Station
ZB164062R34	36"	Rock & Frost Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Rock & Frost Assemblies, 1.654" Every 2nd


Ballantine Part No.	Dig Depth	Description
TA1654HD042R26	24"	Rock & Frost Assembly 4" Cut 26 Station
TA1654HD042R34	36"	Rock & Frost Assembly 4" Cut 34 Station
TA1654HD062R26	24"	Rock & Frost Assembly 6" Cut 26 Station
TA1654HD062R34	36"	Rock & Frost Assembly 6" Cut 34 Station
Wider Cutting Widths Available Upon Request		

Bobcat® LT102 Attachment



Heavy Duty Anti Back Flex Terminator Chain

Ballantine Part No.	Dig Depth	Description
SH165404S26	24"	Terminator Chain 4" Cut 26 Station
SH165404S34	30"	Terminator Chain 4" Cut 34 Station
Wider Cutting Widths Available Upon Request		



Heavy Duty Anti Back Flex Alligator Chain

Ballantine Part No.	Dig Depth	Description
AL16540426	24"	Alligator Chain 4" Cut 26 Station
AL16540434	30"	Alligator Chain 4" Cut 34 Station
Wider Cutting Widths Available Upon Request		

Bobcat® LT102 Attachment

Chain Components For 1.654 Every 4th, Every 2nd And Heavy Duty Anti Back Flex

Chain Repair Components

	Ballantine Part No.	OEM Part Number	Description
	B208454	N/A	Connecting Pin & Keeper
	Ballantine Part No.	OEM Part Number	Description
	B135007	N/A	Cotter Pin
	Ballantine Part No.	OEM Part Number	Description
	ZB1640400B01	N/A	Chain Repair Section Every Fourth
	Ballantine Part No.	OEM Part Number	Description
	ZB1640200B01	N/A	Chain Repair Section Every Second
	Ballantine Part No.	OEM Part Number	Description
	TA1654HD00B01	N/A	Heavy Duty Anti Back Flex Chain Repair Section Every Second

Cup Cutters

	Ballantine Part No.	OEM Part Number	Description
	6655759	6655759	Cup Cutter Right Hand
	Ballantine Part No.	OEM Part Number	Description
	6655760	6655760	Cup Cutter Left Hand

Terminators

	Ballantine Part No.	OEM Part Number	Description
	T165404R	N/A	Terminator Adapter Right Hand
	Ballantine Part No.	OEM Part Number	Description
	T165404L	N/A	Terminator Adapter Left Hand
	Ballantine Part No.	OEM Part Number	Description
	T165404C	N/A	Terminator Adapter Straight Cut

Rock & Frost

	Ballantine Part No.	OEM Part Number	Description
	B135318	N/A	Rock & Frost Adapter Right Hand
	Ballantine Part No.	OEM Part Number	Description
	B135317	N/A	Rock & Frost Adapter Left Hand
	Ballantine Part No.	OEM Part Number	Description
	B135316	N/A	Rock & Frost Adapter Straight Cut
	Ballantine Part No.	OEM Part Number	Description
	B17	N/A	Carbide Bit With Clip
	Ballantine Part No.	OEM Part Number	Description
	B17D	N/A	Clip

Flat Spacers

	Ballantine Part No.	OEM Part Number	Description
	B208355	N/A	Flat Spacer 5/16" Thick
	Ballantine Part No.	OEM Part Number	Description
	BL1654-5	N/A	Flat Spacer 1/2" Thick
	Ballantine Part No.	OEM Part Number	Description
	BL1654-6	N/A	Flat Spacer 1" Thick

Bobcat® LT102 Attachment

Chain Components For 1.654 Every 4th, Every 2nd And Heavy Duty Anti Back Flex

Adapters For 1.654" Pitch Every 4th And Every 2nd




Ballantine Part No.	OEM Part Number	Description
B208439	N/A	Adapter For 8" Cut
Ballantine Part No.	OEM Part Number	Description
B208477	N/A	Adapter For 10" Cut
Ballantine Part No.	OEM Part Number	Description
B564781	N/A	Adapter For 12" Cut

Adapters For 1.654" Pitch Heavy Duty Anti Back Flex



Ballantine Part No.	OEM Part Number	Description
PL1654HD8	N/A	Adapter For 8" Cut
Ballantine Part No.	OEM Part Number	Description
PL1654HD10	N/A	Adapter For 10" Cut
Ballantine Part No.	OEM Part Number	Description
PL1654HD12	N/A	Adapter For 12" Cut

Tube Spacers



Ballantine Part No.	OEM Part Number	Description
B138009	N/A	Tube Spacer For Outside Mounting
Ballantine Part No.	OEM Part Number	Description
B138010	N/A	Tube Spacer Rock & Frost Mounted Inside
Ballantine Part No.	OEM Part Number	Description
B136032S	N/A	Tube Spacer Cup Cutter Mounted Inside


Bolts



Ballantine Part No.	OEM Part Number	Description
3824788	N/A	Bolt 3/8" X 24 X 7/8" Grade 8
Ballantine Part No.	OEM Part Number	Description
34241148	N/A	Bolt 3/8" X 24 X 1 1/4" Grade 8
Ballantine Part No.	OEM Part Number	Description
38242148	N/A	Bolt 3/8" X 24 X 2 1/4" Grade 8
Ballantine Part No.	OEM Part Number	Description
38242128	N/A	Bolt 3/8" X 24 X 2 1/2" Grade 8
Ballantine Part No.	OEM Part Number	Description
38242348	N/A	Bolt 3/8" X 24 X 2 3/4" Grade 8
Ballantine Part No.	OEM Part Number	Description
382438	N/A	Bolt 3/8" X 24 X 3" Grade 8
Ballantine Part No.	OEM Part Number	Description
38243148	N/A	Bolt 3/8" X 24 X 3 1/4" Grade 8
Ballantine Part No.	OEM Part Number	Description
38243128	N/A	Bolt 3/8" X 24 X 3 1/2" Grade 8
Ballantine Part No.	OEM Part Number	Description
3824	N/A	Lock Nut 3/8" X 24
Ballantine Part No.	OEM Part Number	Description
382S	N/A	Flat Washer

Bobcat® LT102 Attachment**Sprocket**

Ballantine Part No.	OEM Part Number	Description
6705174	6705174	Drive Sprocket Solid 11 Tooth

Boom Components

Ballantine Part No.	OEM Part Number	Description
6577026	6577026	Boom End Roller




Ballantine Part No.	OEM Part Number	Description
6577026A	N/A	Boom End Roller Assembly



Ballantine Part No.	OEM Part Number	Description
6576140	6576140	Bearing Square Hole



Ballantine Part No.	OEM Part Number	Description
6645545	6645545	Snap Ring



Ballantine Part No.	OEM Part Number	Description
6577025	6577025	Dirt Shield (2 Required)



Ballantine Part No.	OEM Part Number	Description
6577011	6577025	Idle Shaft



Ballantine Part No.	OEM Part Number	Description
12131	35C000816B	Idle Shaft Bolt (2 Required)



Ballantine Part No.	OEM Part Number	Description
12FW	6675521	Idle Shaft Washer (2 Required)

BALLANTINE

Ground Engaging Parts Specialists

Corporate Headquarters: 840 McKinley Street, Anoka, MN 55303
Warehouse: 9647 Sante Fe Springs Rd., Sante Fe Springs, CA 90680
Warehouse: 675 Wesleyan Drive SW, Atlanta, GA 30336

www.ballantineinc.com
phone: 800-328-2424 • fax 763-427-2277 • parts@ballantineinc.com

©2016 U.S. Tsubaki Power Transmission, LLC. All Rights Reserved
Printed in the U.S.A. 05/17